## \* Work Order ID 82843

April-24-12 7:49:14 AM

\*82843\*

Item ID:

D350-567-025

4/10/12

QC:

Accept

\*N900040100\*

Setup Start

**Revision ID:** 

Item Name: **Start Date:** 

Floor Window Installation, Large

Cust Item ID:

Required Date: 4/20/12

Start Oty: 1.00 Req'd Qty: 1.00

**Customer:** 

Reference:

**Approvals:** 

Process Plan

Date: Date:

Tooling:

Date:

Run Start

Stop

**Operation** 

SPC (Y/N):

Date:

Sequence ID/ Work Center ID

Description

Set Up/ **Run Hours**  Tool ID

Tool # Plan Code Accept Reject Oty

**Qty** 

Reject Number

Insp. Stamp

Draw Nbr

**Revision Nbr** 

N/A

100

Rev D

\*100\*

DOCUMENT CONTROL

Memo

0.00

0.00

Document Control

Copy bluefile and create labels & DT8439 per PPP D350-567-025

8 Mc4/25

CHG002 JB Stelenks

of for MLJ 12-4-24

110

\*110\*

Packaging

Memo

0.00

0.00

Packaging Packaging

Pick Packing Kit\*\*\*ENSURE DT 8439 TEMPLATE IS INCLUDED\*\*\*

Sp 12-4-24

120

QC4- 100% Inspect kits for completeness

0.00

\*120\*

Memo

0.00

Quality Control

# \*82843\*

0.00

Work Order ID 82843

Quality Control

<sup>8</sup>April-24-12 7:49:14 AM Item ID: D350-567-025 Accept \*N900040100\* **Revision ID:** Item Name: Floor Window Installation, Large Start Qty: 1.00 **Start Date:** 4/10/12 Required Date: 4/20/12 **Req'd Qty:** 1.00 \*1\* **Customer:** Reference: Approvals: **Process Plan:** Date: Tooling: QC: Date: SPC (Y/N): Sequence ID/ **Operation** Set Up/ Tool ID **Work Center ID Description Run Hours** 130 0.00 Packaging \*130\* Packaging 0.00 Memo Packaging Identify and pack for shipping as per PPP D35Q-567-025Location: PPP Rev: kit\*\*\*\*\*\*\*\*\*\*\*\*\*\* 140 QC21- Final Inspection - Work Order Release 0.00 \*140\*

Memo

Setup Start

12/4/25 V) ML 12-04-25

# **Picklist Print**

April-24-12 7:49:14 AM

Work Order ID:

82843

Parent Item:

D350-567-025

Parent Item Name:

Floor Window Installation, Large

Comments:

IPP Rev:B Added Cutting Template 05-12-14 JLM IPP Rev:C 08-10-07 as per revD DD verified by:

	Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status		
8	D350-567-023 CHCXO Replacement Window, Larg		Manufactured	No			120	Each	0.0000	1	1	92	841	J BOO		
δ .5	10350-567-031, Hore Interior Floor Window (Slid	(ling Door Compatible)	Manufactured	No			120	Each	0.0000	T.	1	87	844	18 +2/04/2	4	
	DT8439 template		Manufactured	No			120	Each	0.0000	1	. 1		ı	JB 80		

**Start Date:** 4/10/12

Required Date: 4/20/12

Start Qty: 1.00 Required Qty: 1.00

### DART AEROSPACE LTD.

# **REFERENCE ONLY**

D350-567 Page 28 of 28



#### 5.0 **PARTS LIST**

Qty	Qty	. Qty	Qty	Qty	Qty		
-015	-017	-025	-027	-111	-117	Part Number	Description
Х						D350-567-015	FLOOR WINDOW INSTALLATION (SMALL)
	Х					D350-567-017	FLOOR WINDOW INSTALLATION (SMALL)
		Х				D350-567-025	FLOOR WINDOW INSTALLATION (LARGE)
			Х			D350-567-027	FLOOR WINDOW INSTALLATION (LARGE)
				Х		D350-567-111	FLOOR WINDOW INSTALLATION (EXTRA LARGE)
					Х	D350-567-117	FLOOR WINDOW INSTALLATION (EXTRA LARGE)
1	1	_	l		<del> </del>	D350-567-013	REPLACEMENT WINDOW KIT (SMALL)
		1	1			D350-567-023	REPLACEMENT WINDOW KIT (LARGE)
				1	1	D350-567-113	REPLACEMENT WINDOW KIT (EXTRA LARGE)
	1		1	1		D350-567-115	INTERIOR FLOOR WINDOW KIT
1		1			1	D350-567-031	INTERIOR FLOOR WINDOW KIT
		_					(SLIDING DOOR COMPATABLE)

- Ot - 1	64	<u> </u>	~.	<u> </u>		
Qty	Qty	Qty	Qty	Qty		
-013	-023	-113	-115	-031	Part Number	Description
X					D350-567-013	REPLACEMENT WINDOW KIT (SMALL)
<b></b>	Х				D350-567-023	REPLACEMENT WINDOW KIT (LARGE)
		X			D350-567-113	REPLACEMENT WINDOW KIT (EXTRA LARGE)
			Х		D350-567-115	INTERIOR FLOOR WINDOW KIT
				X	D350-567-031	INTERIOR FLOOR WINDOW KIT
						(SLIDING DOOR COMPATABLE)
1					D2125	REPLACEMENT WINDOW, SMALL
	1				D2942	REPLACEMENT WINDOW, LARGE
-	•	1			D3290-041	REPLACEMENT WINDOW ASSEMBLY, EXTRA LARGE
					D3230-041	THE BACEMENT WINDOW ASSEMBLE, EXTINA BANGE
1					D2126-0600	SEAL
	11				D2463-0750	NEOPRENE SEAL
		1			D2463-0860	NEOPRENE SEAL
	9	12			2600-6	1/4 TURN FASTENER
	9	12			2600-LW	WASHER
	9	12			212-12	RECEPTACLE
	22	21			AN526C832R9	SCREW (OR AN526C832-9,OR MS51957-126)
	44	42			AN960JD8	WASHER
	22	21			MS21042L08	NUT (OR MS21042-08)
	18	24			MS20426AD3-5	RIVET
2 SQ.	2 SQ.	2 SQ.			N/A	9.7oz 7781 'S' GLASS UNIVERSAL WEAVE
YD	YD	DY				
				1	D2463-0450	NEOPRENE SEAL
	<del></del>	<del></del>		1	D3210-1	DOUBLER
		<del></del>		1	D3210-1	BRACKET
			ļ	1	D3211-1	FLOOR WINDOW
				1	D3212-1 D3213-041	DOOR ASSEMBLY
			1		D3293-1	DOUBLER
<u> </u>	<u> </u>		1		D3294-1	BRACKET
	<del></del>		1		D3295-041	FLOOR WINDOW
<u> </u>			1		D3296-041	DOOR ASSEMBLY
			1		D2463-0530	NEOPRENE SEAL
			9	8	AN526C632R12	SCREW (OR AN526C632-12, OR MS51957-32)
ļ			9	8	AN960JD6	WASHER
			9	8	MS21042L06	NUT (OR MS21042-06)
			2	40	MS20470AD4-5	RIVET
			115	90	MS20470AD4-6	RIVET .
			15	20	MS20470AD4-7	RIVET

• COPYRIGHT © 2000 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: D

Date: 08.07.08